## **Set Up Instructions**



## **Set Up Instructions**



Insert graphic into channel.

Make sure graphic is centered.

Plug printed foot into bottom wood piece.

## **Set Up Instructions**



Insert dowel to base. Make sure it hits bottom.

Insert middle and top dowel. Make sure dowels are fully inserted and touch each other. Unroll banner with both hands. When close to the top, slide paper tube off.

Step on base and bend hook and dowels to attach.. When taking down, start by sliding paper tube to almost hit the connection point.

After disengaging the hook, roll banner evenly around tube, print side out.