

- Qty. Description ltem
- 38" Q914 Vertical Extrusion

- 38" Q914 Vertical Extrusion 2
- 38" Q914 Vertical Extrusion 3
- 38" Q914 Vertical Extrusion 4 1
- 2/2 15" Z45 Horizontal Extrusion 5/5A
- 32.125" Z45 Horizontal Extrusion 6 4
- 23.25" Z45 Vertical Extrusion w/ Hinges 8 1
- 23.25" Z45 Vertical Extrusion w/ Door Stop 9 1

© 2025

Steps:

- 1) Assemble lower horizontals [5,6] between verticals [1,2,3,4].
- 2) Lock verticals [8,9] onto lower horizontal [6].
- 3) Slide inserts between verticals and place onto lower horizontals.
- 4) Attach upper horizontals [5A,6] between verticals.
- 5) Hang assembled door from hinges. Refer to door detail.
- 6) Velcro attach shelf supports to inside of assembled pedestal.
- 7) Place shelf on shelf supports.
- 8) Place counter top on top of assembled pedestal.





FRONT VIEW









Order #XXXXX General Information

General Setup Instructions

- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.

Cleaning & Packing

- For Cleaning Metal, Plex, & Laminate Parts: Use a MILD NON-ABRASIVE cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure. Heat and UV exposure will warp and fade components.
- Retain all provided Packing Materials. All provided packing materials are for ease of repacking & component protection.

Disassembly

- For loss prevention, tighten all set screws and locks during disassembly.



Spline Connection





Part Identification - Numbering



Base Plate & Extrusion Connection



Extrusion & Lock Connection

Engaged Lock







VARNING

DO NOT USE POWER TOOLS

LADDERS OR LIFTS MAY BE REQUIRED

ALL CONNECTIONS MUST **BE TIGHTLY SECURED**